

```
/*
```

```
CDE/Hygain Rotor Controller  
Emulates Yeasu GS-232A Azimuth Controller  
Written by Glen Popiel, KW5GP
```

```
This program is free software: you can redistribute it and/or modify  
it under the terms of the version 3 GNU General Public License as  
published by the Free Software Foundation.
```

```
This program is distributed in the hope that it will be useful,  
but WITHOUT ANY WARRANTY; without even the implied warranty of  
MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the  
GNU General Public License for more details.
```

```
You should have received a copy of the GNU General Public License  
along with this program. If not, see <http://www.gnu.org/licenses/>.
```

```
*/
```

```
// Debug Mode must be off to communicate with Ham Radio Deluxe  
#define debug_mode 0 // Set to 1 for debug data on Serial Port
```

```
#include <Wire.h> // Include the I2C Communication Library  
#include <EEPROM.h> // Include the EEPROM Library  
#include "ADS1115.h" // Include the ADS1115.h Library (Library Updated to  
fix errors)  
#include "I2Cdev.h" // Include I2Cdev.h Library (Library Updated to fix  
errors)
```

```
ADS1115 adc; // Define the ADS1115 as adc
```

```
#define rotate_left 4 // Define Rotate Left as Pin 4  
#define rotate_right 5 // Define Rotate Right as Pin 5  
#define brake 6 // Define the Brake pin
```

```
#define BAUD_RATE 9600 // Set the Serial Port Baud rate to 9600
```

```
#define EEPROM_ID_BYTE 1 // EEPROM ID to validate EEPROM data location  
#define EEPROM_ID 55 // EEPROM ID Value  
#define EEPROM_AZ_CAL_0 2 // Azimuth Zero Calibration EEPROM location  
#define EEPROM_AZ_CAL_MAX 4 // Azimuth Max Calibration Data EEPROM  
location
```

```
#define AZ_CAL_0_DEFAULT 0 // Preset the Azimuth Zero Calibration  
Point to 0  
#define AZ_CAL_MAX_DEFAULT 7000 // Preset the Azimuth Max  
Calibration Point to 27000
```

```
#define AZ_Tolerance 2 // Set the Azimuth Accuracy Tolerance
```

```
//variables  
byte inByte = 0; // incoming serial byte
```

```

byte serial_buffer[50]; // incoming serial byte buffer
int serial_buffer_index = 0; // The index pointer variable for the
Serial buffer
int set_AZ; // Azimuth set value
int current_AZ; // Current Azimuth raw value
String Serial_Send_Data; // Data to send to Serial Port
int AZ_0; // Azimuth Zero Value from EEPROM
int AZ_MAX; // Azimuth Max Value from EEPROM
int AZ_Degrees; // mapped AZ ADC value to Degrees
String Requested_AZ; // RS232 Requested Azimuth - M and short W command
int AZ_To; // Requested AZ Move
int AZ_Distance; // Distance to move AZ

void setup()
{
    pinMode(rotate_left, OUTPUT); // Define the Control Pins as Outputs
    pinMode(rotate_right, OUTPUT);
    pinMode(brake, OUTPUT);

    digitalWrite(rotate_left, LOW); // Turn off all the relays just to be
sure
    digitalWrite(rotate_right, LOW);
    digitalWrite(brake, LOW);

    Serial.begin(BAUD_RATE); // initialize serial communication

    Wire.begin(); // join I2C bus

    adc.initialize(); // initialize ADS1115 16 bit A/D chip

    Wire.beginTransmission(0x48); // Begin direct ADC communication
    Wire.write(0x1); // Connect to adc and send two bytes - Set Config
Reg to all Ones
    Wire.write(0x7F); // MSB
    Wire.write(0xFF); // LSB
    Wire.endTransmission(); // End the direct ADC Communication

    adc.setMode(ADS1115_MODE_CONTINUOUS); // Set the ADC to free running
conversion mode
    adc.setGain(ADS1115_PGA_0P256); // set the ADC gain to 0.256 Volt
range, 0.007813 Volts/step
    adc.setRate(ADS1115_RATE_32); // set ADC sample rate to 32 samples per
second
    adc.setMultiplexer(ADS1115_MUX_P0_N1); // Set the ADC to AN0+ AN1
Differential Mode

    set_AZ = -1; // Preset the Azimuth and Elevation Move Variables

    read_eeprom_cal_data(); // Read the Azimuth and Elevation Calibration
Values from EEPROM
} // End Setup Loop

void loop()

```

```

{
    check_serial(); // Check the Serial Port for Data
    check_move(); // Check to see if executing move command
} // End Main Loop

// Functions

void read_eeprom_cal_data() // Function to Read the Azimuth and
Elevation Calibration Data
{
    if (EEPROM.read(EEPROM_ID_BYTE) == EEPROM_ID) // Verify the EEPROM has
valid data
    {
        if (debug_mode) // If in Debug Mode Print the Calibration Values
        {
            Serial.println("Read EEPROM Calibration Data Valid ID");
            Serial.println((EEPROM.read(EEPROM_AZ_CAL_0) * 256) +
EEPROM.read(EEPROM_AZ_CAL_0 + 1), DEC);
            Serial.println((EEPROM.read(EEPROM_AZ_CAL_MAX) * 256) +
EEPROM.read(EEPROM_AZ_CAL_MAX + 1), DEC);
        }

        AZ_0 = (EEPROM.read(EEPROM_AZ_CAL_0)*256) +
EEPROM.read(EEPROM_AZ_CAL_0 + 1); // Read the Azimuth Zero Calibration
Value from EEPROM
        AZ_MAX = (EEPROM.read(EEPROM_AZ_CAL_MAX)*256) +
EEPROM.read(EEPROM_AZ_CAL_MAX + 1); // Read the Azimuth Maximum
Calibration Value from EEPROM

    } else { // initialize eeprom to default values
        if (debug_mode)
        {
            Serial.println("Read EEPROM Calibration Data Invalid ID - setting to
defaults");
        }
        AZ_0 = AZ_CAL_0_DEFAULT; // Set the Calibration To Default Values
        AZ_MAX = AZ_CAL_MAX_DEFAULT;
        write_eeprom_cal_data(); // Write the Default Values to EEPROM
    }
}

void write_eeprom_cal_data() // Function to Write the Calibration Values
to EEPROM
{
    Serial.println("Writing EEPROM Calibration Data");

    EEPROM.write(EEPROM_ID_BYTE, EEPROM_ID); // Write the EEPROM ID
    EEPROM.write(EEPROM_AZ_CAL_0, highByte(AZ_0)); // Write the Azimuth
Zero Calibration High Order Byte
    EEPROM.write(EEPROM_AZ_CAL_0 + 1, lowByte(AZ_0)); // Write the
Azimuth Zero Calibration Low Order Byte
    EEPROM.write(EEPROM_AZ_CAL_MAX, highByte(AZ_MAX)); // Write the Azimuth
Max Calibration High Order Byte

```

```

EEPROM.write(EEPROM_AZ_CAL_MAX + 1,lowByte(AZ_MAX)); // Write the
Azimuth Max Calibration Low Order Byte
}

void check_serial() // Function to check for data on the Serial port
{
  if (Serial.available() > 0) // Get the Serial Data if available
  {
    inByte = Serial.read(); // Get the Serial Data

    // You may need to uncomment the following line if your PC software
    // will not communicate properly with the controller
    // Serial.print(char(inByte)); // Echo back to the PC

    if (inByte == 10) // ignore Line Feeds
    {
      return;
    }
    if (inByte !=13) // Add to buffer if not CR
    {
      serial_buffer[serial_buffer_index] = inByte;

      if (debug_mode) // Print the Character received if in Debug mode
      {
        Serial.print("Received = ");
        Serial.println(serial_buffer[serial_buffer_index]);
      }

      serial_buffer_index++; // Increment the Serial Buffer pointer
    } else { // It's a Carriage Return, execute command

      if ((serial_buffer[0] > 96) && (serial_buffer[0] < 123)) //If first
character of command is lowercase, convert to uppercase
      {
        serial_buffer[0] = serial_buffer[0] - 32;
      }

      switch (serial_buffer[0]) { // Decode first character of command

        case 65: // A Command - Stop the Azimuth Rotation

          if (debug_mode) {Serial.println("A Command Received");}
          az_rotate_stop();
          break;

        case 67: // C - return current azimuth

          if (debug_mode) // Return the Buffer Index Pointer in Debug
Mode
          {
            Serial.println("C Command Received");
            Serial.println(serial_buffer_index);
          }

```

```

    send_current_az(); // Return Azimuth if C Command
    break;

case 70: // F - Set the Max Calibration

    if (debug_mode)
    {
        Serial.println("F Command Received");
        Serial.println(serial_buffer_index);
    }
    set_max_az_cal(); // F - Set the Max Azimuth Calibration
    break;

case 76: // L - Rotate Azimuth CCW

    if (debug_mode)
    {
        Serial.println("L Command Received");
    }
    rotate_az_ccw(); // Call the Rotate Azimuth CCW Function
    break;

case 77: // M - Rotate to Set Point

    if (debug_mode)
    {
        Serial.println("M Command Received");
    }
    rotate_to(); // Call the Rotate to Set Point Command
    break;

case 79: // O - Set Zero Calibration

    if (debug_mode)
    {
        Serial.println("O Command Received");
        Serial.println(serial_buffer_index);
    }
    set_0_az_cal(); // O - Set the Azimuth Zero Calibration
    break;

case 82: // R - Rotate Azimuth CW

    if (debug_mode)
    {
        Serial.println("R Command Received");
    }
    rotate_az_cw(); // Call the Rotate Azimuth CW Function
    break;

case 83: // S - Stop All Rotation

    if (debug_mode)
    {

```

```

        Serial.println("S Command Received");
    }
    az_rotate_stop(); // Call the Stop Azimuth Rotation Function
    break;

}

    serial_buffer_index = 0; // Clear the Serial Buffer and Reset the
Buffer Index Pointer
    serial_buffer[0] = 0;
}
}
}

void send_current_az() // Send the Current Azimuth Function
{
    read_adc(); // Read the ADC

    // Map Azimuth to degrees
    if (debug_mode)
    {
        Serial.println(current_AZ);
    }
    AZ_Degrees = map(current_AZ, AZ_0, AZ_MAX, 0, 360); // Map the Current
Azimuth to Degrees
    if (AZ_Degrees > 180) // Correction Since Azimuth Reading starts at
Meter Center Point
    {
        AZ_Degrees = AZ_Degrees - 180;
    } else {
        AZ_Degrees = AZ_Degrees + 180;
    }
    if (debug_mode)
    {
        Serial.println(AZ_Degrees);
    }
    // Send it back via serial
    Serial_Send_Data = "";
    if (AZ_Degrees < 100) // pad with 0's if needed
    {
        Serial_Send_Data = "0";
    }
    if (AZ_Degrees < 10)
    {
        Serial_Send_Data = "00";
    }
    Serial_Send_Data = "+0" + Serial_Send_Data + String(AZ_Degrees); //
Send the Azimuth in Degrees
    Serial.println(Serial_Send_Data); // Return value via RS-232 port
}

void set_max_az_cal() // Set the Max Azimuth Calibration Function
{
    Serial.println("Calibrate Max AZ Function");
}

```

```

    read_adc(); // Read the ADC

    // save current az and el values to EEPROM - Zero Calibration
    Serial.println(current_AZ);

    AZ_MAX = current_AZ; // Set the Azimuth Maximum Calibration to Current
Azimuth Reading
    write_eeprom_cal_data(); // Write the Calibration Data to EEPROM
    Serial.println("Max Azimuth Calibration Complete");
}

void rotate_az_ccw() // Function to Rotate Azimuth CCW
{
    digitalWrite(brake, HIGH); // Release the brake
    digitalWrite(rotate_left, HIGH); // Set the Rotate Left Pin High
    digitalWrite(rotate_right, LOW); // Make sure the Rotate Right Pin is
Low
}

void rotate_az_cw() // Function to Rotate Azimuth CW
{
    digitalWrite(brake, HIGH); // Release the brake
    digitalWrite(rotate_right, HIGH); // Set the Rotate Right Pin High
    digitalWrite(rotate_left, LOW); // Make sure the Rotate Left Pin Low
}

void az_rotate_stop() // Function to Stop Azimuth Rotation
{
    digitalWrite(rotate_right, LOW); // Turn off the Rotate Right Pin
    digitalWrite(rotate_left, LOW); // Turn off the Rotate Left Pin
    set_AZ = -1;
    delay(1000);
    digitalWrite(brake, LOW); // Engage the brake
}

void rotate_to() // Function to Rotate to Set Point
{
    if (debug_mode)
    {
        Serial.println("M Command - Rotate Azimuth To Function");
    }
    // Decode Command - Format Mxxx - xxx = Degrees to Move to
    if (debug_mode)
    {
        Serial.println(serial_buffer_index);
    }
    if (serial_buffer_index == 4) // Verify the Command is the proper
length
    {
        if (debug_mode)
        {
            Serial.println("Value in [1] to [3]?");
        }
    }
}

```

```

    Requested_AZ = (String(char(serial_buffer[1])) +
String(char(serial_buffer[2])) + String(char(serial_buffer[3]))) ; //
Decode the Azimuth Value
    AZ_To = (Requested_AZ.toInt()); // AZ Degrees to Move to as integer
    if (AZ_To < 0) // Make sure we don't go below 0 degrees
    {
        AZ_To = 0;
    }
    if (AZ_To > 360) // Make sure we don't go over 360 degrees
    {
        AZ_To = 360;
    }
    if (AZ_To > 180) // Adjust for Meter starting at Center
    {
        AZ_To = AZ_To - 180;
    } else {
        AZ_To = AZ_To + 180;
    }
    if (debug_mode)
    {
        Serial.println(Requested_AZ);
        Serial.println(AZ_To);
    }

    // set the move flag and start
    read_adc(); // Read the ADC

    // Map it to degrees
    if (debug_mode)
    {
        Serial.println(current_AZ);
    }
    AZ_Degrees = map(current_AZ, AZ_0, AZ_MAX, 0, 360); // Map the
Azimuth Value to Degrees
    if (debug_mode)
    {
        Serial.println(AZ_Degrees);
    }
    AZ_Distance = AZ_To - AZ_Degrees; // Figure out far we have to move
    set_AZ = AZ_To;
    if (abs(AZ_Distance) <= AZ_Tolerance) // No move needed if we're
within the Tolerance Range
    {
        az_rotate_stop(); // Stop the Azimuth Rotation
        set_AZ = -1; // Turn off the Move Command
    } else { // Move Azimuth - figure out which way
        if (AZ_Distance > 0) //We need to move CW
        {
            rotate_az_cw(); // If the distance is positive, move CW
        } else {
            rotate_az_ccw(); // Otherwise, move counterclockwise
        }
    }
}
}

```



```

}

void set_0_az_cal() // Set Azimuth Zero Calibration
{
    Serial.println("Calibrate Zero Function");

    read_adc(); // Read the ADC
    // save current Azimuth value to EEPROM - Zero Calibration
    Serial.println(current_AZ);

    AZ_0 = current_AZ; // Set the Azimuth Zero Calibration to current
position
    write_eeprom_cal_data(); // Write the Calibration Data to EEPROM
    Serial.println("Zero Azimuth Calibration Complete");
}

void read_adc() // Function to read the ADC
{
    if (debug_mode)
    {
        Serial.println("Read ADC Function  ");
    }

    int RotorValue; // Variable to store the rotor value
    adc.setRate(ADS1115_RATE_32); // Set the ADC rate to 32 samples/sec
    adc.setGain(ADS1115_PGA_0P256); // Set the ADC gain to 0.007813 Volts
    adc.setMultiplexer(ADS1115_MUX_P0_N1); // Set the ADC to Channel 0
    AN0+ AN1 Differential Mode
    delay(100); // adc settling delay

    current_AZ = adc.getDifferential(); // Read ADC Channel 0 and 1
Differentially
}

void check_move() // Check to see if we've been commanded to move
{
    if (set_AZ != -1) { // We're moving - check and stop as needed
        read_adc(); // Read the ADC
        // Map AZ to degrees
        if (debug_mode)
        {
            Serial.println(current_AZ);
        }
        AZ_Degrees = map(current_AZ, AZ_0, AZ_MAX, 0, 360); // Map the
Current Azimuth reading to Degrees

        if (debug_mode)
        {
            Serial.println(AZ_Degrees);
        }

        if (set_AZ != -1) // If Azimuth is moving
        {

```

```

        AZ_Distance = set_AZ - AZ_Degrees; // Check how far we have to
move
        if (abs(AZ_Distance) <= AZ_Tolerance) // No move needed if we're
within the tolerance range
        {
            az_rotate_stop(); // Stop the Azimuth Rotation
            set_AZ = -1; // Turn off the Azimuth Move Command
        } else { // Move Azimuth - figure out which way
            if (AZ_Distance > 0) //We need to move CW
            {
                rotate_az_cw(); // Rotate CW if positive
            } else {
                rotate_az_ccw(); // Rotate CCW if negative
            }
        }
    }
}

```